

# Vibration Energy Harvesting

**Professor Yuji Suzuki**

**Department of Mechanical Engineering**

**The University of Tokyo, Japan**

**e-mail: [ysuzuki@mesl.t.u-tokyo.ac.jp](mailto:ysuzuki@mesl.t.u-tokyo.ac.jp)**




**東京大学**  
THE UNIVERSITY OF TOKYO

# Objective

**Experience vibration energy harvesting using piezoelectric cantilever**

- ✓ **Calculate the length of cantilever and the tip mass to satisfy the given resonance frequency.**
- ✓ **Carry out simple power generation experiment using the piezoelectric cantilever.**

# Linear Beam Theory



$$dx = \rho d\theta$$

$$dL = (\rho - z) d\theta$$

$$= dx - \frac{z}{\rho} dx$$

$$\epsilon_x = -\frac{z}{\rho}$$

Strain

$$\sigma_x = -\frac{z}{\rho} E$$

Stress

$$M = \int_{-H/2}^{H/2} W z \sigma_x dz$$



Moment

$$= -\frac{EI}{\rho}$$

$$I = \frac{1}{12} WH^3$$

Moment of  
inertia

# Linear Beam Theory



$$ds = \rho d\theta$$

$$ds = \frac{dx}{\cos \theta}$$

$$\frac{dy}{dx} = \tan \theta$$

$$\frac{d^2 y}{dx^2} = \frac{1}{\cos^2 \theta} \frac{d\theta}{dx}$$

$$\frac{1}{\rho} = \frac{d^2 y / dx^2}{\left\{ 1 + \left( \frac{dy}{dx} \right)^2 \right\}^{3/2}} \sim \frac{d^2 y}{dx^2}$$



$$\frac{d^2 y}{dx^2} = -\frac{M}{EI}$$

$$= \frac{1}{EI} \cdot F(L - x)$$

B.C.

$$\begin{cases} y(0) = 0 \\ \frac{dy}{dx}(0) = 0 \end{cases}$$

# Spring Constant of a Cantilever Beam




$$\frac{d^2 y}{dx^2} = \frac{1}{EI} \cdot F(L - x)$$

$$y(x) = \frac{FL}{2EI} x^2 \left( 1 - \frac{x}{3L} \right)$$

$$y_{\max} = y(L) = \frac{L^3}{3EI} \cdot F$$

$$k = \frac{y_{\max}}{F} = \frac{3EI}{L^3} = \frac{WH^3}{4L^3} E$$

When the mass of cantilever is neglected, the resonant frequency becomes



$$\omega = \sqrt{\frac{k}{M}} = \sqrt{\frac{3EI}{ML^3}} = \sqrt{\frac{WH^3}{4ML^3}} E$$

How about  $\omega$  with finite mass of the beam?

# Derivation with the Energy Method

$V$  : Kinetic energy

$T$  : Strain energy

$$V + T = \text{const.}$$

$$\frac{d}{dt}(V + T) = 0$$

$$\frac{d}{dt}\left(\frac{1}{2}m\dot{x}^2 + \frac{1}{2}kx^2\right) = 0$$

$$\therefore m\ddot{x}\dot{x} + k\dot{x}x = 0$$

$$\therefore m\ddot{x} + kx = 0$$

$$\therefore \omega = \sqrt{\frac{k}{m}}$$

$V_{\max}$  : Kinetic energy

$T_{\max}$  : Strain energy

$$V_{\max} = T_{\max}$$


$$\frac{1}{2}m\dot{x}_{\max}^2 = \frac{1}{2}kx_{\max}^2$$

$$x_{\max} = x_0, \dot{x}_{\max} = \omega x_0$$

$$\therefore \frac{1}{2}m(\omega x_0)^2 = \frac{1}{2}kx_0^2$$

$$\therefore \omega = \sqrt{\frac{k}{m}}$$

# Derivation with Energy Method



$$k = \frac{y_{\max}}{F} = \frac{3EI}{L^3}$$

$$\therefore 2T = k \cdot y(L)^2 = \frac{3EI}{L^3} y(L)^2$$

Beam shape with applied force  $F$  at the tip

$$\begin{aligned} y(x) &= \frac{FL}{2EI} x^2 \left( 1 - \frac{x}{3L} \right) \\ &= \frac{y(L)}{2L^3} (3Lx^2 - x^3) \end{aligned}$$

$$2V = \omega^2 \left\{ M \cdot y(L)^2 + \int_0^L \frac{m}{L} y^2 dx \right\}$$

$$\frac{2V}{\omega^2} \approx M \cdot y(L)^2 +$$


$$\int_0^L \frac{m}{L} \frac{y(L)^2}{4L^6} (3Lx^2 - x^3)^2 dx$$

$$= y(L)^2 \left( M + \frac{33}{140} m \right)$$

With  $2T = 2V$

$$\therefore \omega^2 = \frac{3EI}{\left( M + \frac{33}{140} m \right) L^3}$$

# Specification of Piezoelectric Cantilever



Material: PZT -  $\text{Pb}(\text{Zr} \cdot \text{Ti})\text{O}_3$

Thickness of PZT: 0.2 mm on each side

Young's modulus: 59 GPa

Density:  $7.75 \text{ g/cm}^3$

Relative permittivity: 5500

Capacitance: 105 nF

$d_{33} = 640 \times 10^{-12} \text{ C/N}$

$d_{31} = -330 \times 10^{-12} \text{ C/N}$

Total thickness: 0.5 mm

Width: 6 mm


Length: 55 mm

## Design Target


**Choose the length of the piezoelectric cantilever and the added mass to get the resonant frequency of 30Hz.**



# Estimate of EI for Multi-layer Structure



# Parameters of Piezoelectric Cantilever



**$L$ :** Length of the cantilever (from the tip to the clamp)


**$M$ :** Mass of the magnet (At least a pair of magnet should be put on both sides of the cantilever.)

**Permanent magnet:**

Small: 6 mm x 6 mm x 3 mm, 0.81 g

Large: 6 mm x 6 mm x 6 mm, 1.62 g

# Experimental Setup



Oscilloscope

Monitor the voltage output

Accelerometer

Monitor the acceleration

Amplifier

Change frequency and acceleration

